

# SPARTACOTE<sup>TM</sup> Seal PURE Flooring Installation Guide TDS-1440

LATICRETE® Australia strongly recommends the use of experienced coating contractors who have demonstrated their commitment to their craft and taken the time to stay current with the latest materials and methods. Requiring references and a portfolio along with a bid or estimate is a good way to ensure the contractor has successfully completed work of similar size, scope, and complexity. Please read application instructions in their entirety prior to installation and contact LATICRETE with any question before you begin any coating project.

LATICRETE resinous flooring products are manufactured with the highest regard for quality, functionality and performance. The following provides a guideline to the proper installation of the SPARTACOTE<sup>TM</sup> Seal PURE flooring system. To install the SPARTACOTE Seal PURE flooring system you should follow the installation guidelines below:

# **SUBSTRATE PREPARATION**

Always mechanically prepare (profile) the surface. An open, porous surface is necessary for proper bonding. The surface must be deemed structurally and mechanically sound, clean, and dry. Proper surface preparation is required for decorative concrete, thin-film "Class-A-type" flooring systems. This is best achieved with mechanical grinding machines using diamond heads achieving a final 30 to 100-grit profile. Recommended surface profile is a CSP-2, Reference ICRI Technical Guideline No. 03732. Surfaces to be coated must be free of previous coatings, sealers, grease, and other contaminants that may impede adhesion. Always check the surface for any bond inhibitors prior to application. DO NOT USE alcohol to clean or tack substrate or previous coat prior to application. Any repairs must be addressed prior to application and should be repaired in accordance with ICRI standards. A moisture emission measurement system is necessary to assess the moisture drive of a concrete slab prior to installation of any toppings or coatings. The maximum amount of moisture in the concrete/mortar bed substrate should not exceed 170 µg/s m²/24 hrs per ASTM F-1869 or 75% relative humidity as tested per ASTM F2170 Relative Humidity in Concrete Slab test. If there is a moisture emission situation in excess of the above rate, the use of LATICRETE Vapour Reduction Coating will be necessary prior to the application of the floor coating.

### APPLICATION METHODS

All methods require the use of 45cm 9mm nap soft woven roller covers, 15cm weenie rollers and/or 7.5cm chip brushes. All methods described below will incorporate a "cut-in" around the perimeter. The cut in should stay just ahead of the main floor application. Product should be dry to the touch in 1-2 hours following application. Material may be applied using one of the following techniques:

### Perimeter Cut-In

Some systems require the use of 15cm weenie rollers and/or 7.5cm chip brushes to effectively "cut-in" around the perimeter of the project. The cut in should stay just ahead of the main floor application

### Dip & Roll

The dip and roll technique will incorporate the use of an 45cm roller and pan. After pouring your already mixed material into your roller pan, fully saturate the roller. Apply the material in one direction followed by a perpendicular back roll in the opposite direction. This method works well if you're working in sections that stop at a control joint.

### Ribbon & Roll

The ribbon and roll technique will consist of pouring the mixed material out in a "ribbon" approximately 22 -30cm wide by the length of the area to be coated. While standing over the ribbon spread the material using an 45cm roller. This should be done working in an area approximately 2.4m wide (ribbon should be placed in the center of the area in which you are working) moving your way down the length of the ribbon while ensuring an even, uniform application of the material. The next ribbon should be placed in the center of the next 2.4 m section and 1.2 m from the "wet edge" of your previous application.

# Top/ Seal Coat Broom & Roll

For larger square footage installation, applicators may find it advantageous to incorporate an asphalt seal-coat broom. Pour a ribbon of material at the back wall or starting point, spread the material using the broom (exactly as you would with a notched squeegee).

# **MIXING MATERIAL**

Non-Pigmented Clear Coats:

Do not mix until ready for immediate use. Using a separate mixing vessel combine the SPARTACOTE<sup>TM</sup> FLEX PURE<sup>TM</sup> parts A&B in equal 1:1 amounts by volume for 2 minutes with a slow speed drill or paddle mixer making sure to scrape the sides and bottom of the bucket. Avoid creating a vortex, as it will induce air to the mix.

### APPLYING THE PRODUCT

Application of Primer Coat: Following surface preparation, be certain that the substrate is free of any excessive concrete dust, moisture or other contaminants. SPARTACOTE FLEX<sup>TM</sup> PURE Clear should be installed at a rate of 18.6m²/3.8L using one of the suggested application methods above. Remember to always complete the application with a back-roll. Allow Coat to dry before top coat is to be applied, typically 2-3 hours. Application of Top Coat: Top coat will consist of a second Clear coat of SPARTACOTE<sup>TM</sup> FLEX PURE<sup>TM</sup> applied at a rate of 18.6m²/3.8L. SPARTACOTE FLEX PURE top coat material can be applied using any of the methods described above, dip and roll, ribbon and roll, Spartacote broom and roll, or squeegee and roll. Optional SPARTACOTE Grip<sup>TM</sup> traction additive may be used in the top coat to provide for increased texture and traction.

# **CURE/ POST COMPLETION**

The floor should be monitored for two hours to prevented foot traffic and should remain out of service for 24 hours before returning the normal use. LATICRETE polyaspartic floor coating systems are nonporous, causing dirt and contaminants to remain on the surface. However, these contaminants can act as abrasives and if not removed regularly can mar the finish on the floor over time. Refer to TDS1420 SPARTACOTE Floor Maintenance Guide for information regarding Recommended Maintenance of your flooring system.

LATICRETE Australia Pty Ltd • 29 Telford Street, Virginia, QLD 4014 Australia 1800 331 012 | technicalsupport@laticrete.com.au | www.laticrete.com.au